


SeaShield Marine Systems



Structurally repaired timber piles with rebar, concrete and translucent SeaShield Fiber-Form fiberglass pile jackets.

Fiber-Form Pile Jacket

Fiberglass jacket to provide a form for encasement of concrete or epoxy grout

SeaShield Fiber-Form Jacket is a custom fabricated fiberglass jacket to structurally restore and protect concrete, timber, and steel piles. The Fiber-Form Jacket is of the highest quality construction to meet Engineering Specifications to withstand hostile marine environments. The Fiber-Form Jacket can be removed or stay in place to protect and extend the life of the restored pile.

Features

- Outstanding abrasion resistance
- Easy to install
- High impact resistance
- UV resistant
- Non-corrosive
- Lightweight
- Manufactured to be translucent or gel coated to a color
- Long maintenance-free service life

Denso[®]
DENSO NORTH AMERICA



Structurally repaired timber piles with rebar, concrete and translucent SeaShield Fiber-Form fiberglass jackets. The jackets can be manufactured to be translucent or gel coated to a color.

Materials

The SeaShield Fiber-Form Jacket is a high quality formulation of Fiberglass Reinforced Plastic (FRP) and polyester resins with UV inhibitors. The pile jackets can be fabricated from 1' to 20' long sections and with a thickness from 1/8" to 3/16" (other thicknesses are available upon request).


The Fiber-Form Jacket is provided with a vertical closure. Denso can install pumping ports at desired locations to attach concrete or epoxy grout hose. Non-corrosive standoffs (grout spacers) can be used inside the jacket to maintain proper spacing around the piling when using SeaShield 550 Epoxy Grout, SeaShield 510 UW Grout or other specified concrete grout.

For further details please refer to the technical data sheet for SeaShield Fiber-Form.



Application

1. Thoroughly clean the existing pile by waterblasting, sandblasting or other acceptable methods. The SeaShield Fiber-Form Jacket can be installed at the tidal zone area or positioned below the mudline.
2. If a mudline repair is required, excavate the mud at the base of the pile and install a jacket. If tidal zone repair is required, install a work platform at the proper height using friction clamps secured to the pile.
3. Install steel or other reinforcement to the pile as required by project specifications.
4. Install stand-offs to provide proper annulus space between rebar and inside of Fiber-Form.
5. Position the Fiber-Form Jacket around the pile and secure with a select strapping system every 18 inches or as required.
6. Prepare bottom seal with SeaShield 550 Epoxy Grout or approved concrete and allow to set. Pumping shall not commence until bottom seal is fully cured.
7. Fill Fiber-Form with SeaShield 510 UW Grout or cementitious grout. Fill jacket at a constant slow rate of placement within allowable pressure ratings.



Find Out More

Contact Denso North America for a complete literature package or a no-cost on-site evaluation of your application:

1-888-821-2300

Denso[®]

DENSO NORTH AMERICA

HOUSTON:
9747 Whithorn Drive,
Houston, Texas,
U.S.A. 77095
Tel: 281-821-3355
Fax: 281-821-0304

TORONTO:
90 Ironside Crescent,
Unit 12, Toronto,
Ontario, Canada M1X1M3
Tel: 416-291-3435
Fax: 416-291-0898

e-mail: info@densona.com

www.densona.com

A Member of Winn & Coales International

FIBER-FORM PILE JACKET

Fiberglass Form for Encasement of Concrete or Epoxy Grout

Description

SeaShield Fiber-Form Pile Jacket is a custom fabricated fiberglass jacket used as a form to structurally restore and protect concrete, timber, and steel piles. The jackets are a high quality formulation of Fiberglass Reinforced Plastic (FRP) and polyester resins. They can be fabricated from 1' to 20' long sections and with a standard thickness of 1/8" or 3/16" (other thicknesses are available upon request). They can be removed or stay in place to protect and extend the life of the restored pile. The Fiber-Form Jackets are of the highest quality construction to meet Engineering Specifications to withstand hostile marine environments.

Features

- Outstanding abrasion resistance
- Easy to install
- High impact resistance
- UV resistant when gel-coated
- Non-corrosive
- Lightweight
- Manufactured to be translucent and or gel coated to a color
- Long maintenance-free service life

Application

Thoroughly clean the existing pile by waterblasting, sandblasting or other acceptable methods. The SeaShield Fiber-Form Jacket can be installed at the tidal zone area or positioned below the mudline. If a mudline repair is required, excavate the mud at the base of the pile and install a jacket. If tidal zone repair is required, install a work platform at the proper height using friction clamps secured to the pile. Install steel or other reinforcement with PVC pipe for proper spacing between the outside of the steel reinforcement and the inside the Fiber-Form Jacket as required by project specifications. Position the Fiber-Form Jacket around the pile and secure with a select strapping system every 18 inches or as required. Fill jacket at a constant slow rate of placement within allowable pressure ratings.

If installing SeaShield Fiber-Form Jacket with SeaShield Series 550 Epoxy Grout, please refer to the SeaShield Series 500 Specifications.



Fiber-Form Pile Jacket

Property Specifications

PROPERTIES	TEST METHOD	GAUGE
Minimum Ultimate Tensile Strength	ASTM D638	16,000 psi
Minimum Ultimate Flexural Strength	ASTM D796	25,000 psi
Flexural Modulus of Elasticity	ASTM D790	800,000 psi
Barcol Hardness	ASTM D2583	45
IZOD Imapct (notched)	ASTM D256	20 ft-lbf/inch
Minimum Water Absorption	ASTM D570	<1%
Relative Permittivity @ 60 Hz	ASTM D150	4.40
Standard Color	—	Translucent
Wall Thickness	—	1/8 in.*

*Other thicknesses (3/16" or 1/4") are available on request.



DENSO NORTH AMERICA

HOUSTON:
9747 Whithorn Drive,
Houston, Texas,
U.S.A. 77095
Tel: 281-821-3355
Fax: 281-821-0304

TORONTO:
90 Ironside Crescent,
Unit 12, Toronto,
Ontario, Canada M1X1M3
Tel: 416-291-3435
Fax: 416-291-0898

www.densona.com

A Member of Winn & Coales International

The information given on this sheet is intended as a general guide only and should not be used for specification purposes. We believe the information to be accurate and reliable but do not guarantee it. We assume no responsibility for the use of this information. Users must, by their own tests, determine the suitability of the products and information supplied by us for their own particular purposes. No patent liability can be assumed.