

PROTAL AIR CARTRIDGE GUN (1000 ml)

For Spraying Protal 7200 Cartridges (1000 ml)

Description

The Protal Air Cartridge Gun is designed for use where fast and easy setup, no clean up, minimal material waste and minimal equipment maintenance is needed. It is based on a reliable design with proven dependability and service. The Protal Air Cartridge Gun has a quick connect/disconnect hose assembly for easy attachment of air lines to the spray manifold. The atomizer air line is also equipped with an air flow regulator and pressure gauge to properly control the air flow and spray pattern. Protal Repair Cartridges should be heated to approx. 120°F to 130°F to ensure optimal spray results.

Features

- Low cost, easy to use, lightweight and portable
- Uses a spray manifold/static mixer assembly
- Dispensing is accomplished with an economical modified air gun that provides controlled dispensing
- Added control of airflow volume and pressure allows for complete material mixing and atomization



Protal Air Cartridge Gun (1000 ml)
(Protal 7200 Cartridge and Static Mixing Tip sold separately).

Denso[®]

Application



1.0 Attach Air Supply

1.1 Confirm the quick-disconnect fitting is the proper size for your air supply hose. Other fittings may be substituted if needed.

1.2 Push the nozzle air hose firmly onto the connector on the regulator.

1.3 Make sure the ball valve is closed before attaching air supply hose to the unit.

2.0 Install Cartridge In Applicator

2.1 Heat Protal Repair Cartridge to approx. 120°F to 130°F in a microwave or convection oven. (Do not overheat).

2.2 Before installing cartridges into gun, hold gun in an upright position while pointing the nozzle in a safe direction away from yourself and other personnel. This will reduce the chance of material drooling into the mixer bell housing causing premature cure of material in mixer.

2.3 Place the large end of the cartridge assembly (piston seal end) over the two ejector plates of the applicator, pushing the cartridge assembly towards the air cylinder, snapping the cartridge into place. Ensure that the cartridge assembly is properly seated in cradle of gun and ejector plates and rod assembly are properly aligned in applicator.

2.4 Place the bell end of the mix nozzle over the cartridge outlet. Press firmly to seat the nozzle.

2.5 Thread the nut assembly clockwise onto the cartridge outlet and tighten securely.

2.6 Attach elbow connector on nozzle air hose firmly onto the nozzle inlet.

3.0 Using the Protal Air Cartridge Gun

3.1 Point applicator upward and attach air supply hose to the regulator. The air supply pressure should be 90-110 psi.

3.2 Set fluid setting dial to #2 or #3 .

3.3 Purge cartridge and nozzle by first pointing the nozzle up and pulling the trigger just long enough to fill the mix nozzle with material; release the trigger before actually dispensing material from the nozzle.

Note: Do not open the ball valve until after the cartridge and nozzle have been purged.

3.4 Point the nozzle in a safe direction and open the ball valve to start the air flow to the nozzle.

3.5 Turn regulator knob to adjust air pressure to approx. 50 to 60 psi.

3.6 Pull trigger to spray. Release to stop spraying.

3.7 Close the ball valve to stop the air flow to the nozzle.

4.0 Remove Cartridge from Applicator

4.1 While pressing the air return button, pull the trigger to retract the ejector plates from the cartridge. Or, push the return pusher toward the air cylinder to retract the ejector plates from the cartridge.

4.2 Remove the air supply hose from the regulator.

4.3 Remove the elbow connector on nozzle air hose from the nozzle inlet.

Note: Do not discard the 90° elbow connector. It is not necessary to remove the connector from the nozzle air hose.

4.4 While holding back the return button, push the cartridge assembly towards the air cylinder and lift out of the applicator cradle.

4.5 Partially-used cartridges may be reused by removing and discarding the nozzle and resealing the cartridge with the original plug. Be sure to re-align the plug according to the A and B compounds.

Note: Refer to the Protal 7200 MSDS (Parts A and B) and applicable regulations or authorities for waste disposal.

5.0 Cleaning

5.1 Wipe off excess coating material with a clean rag and a small amount of solvent, avoiding getting solvent on regulator and piston housing.

Denso®

DENSO NORTH AMERICA

HOUSTON:
9747 Whithorn Drive,
Houston, Texas,
U.S.A. 77095
Tel: 281-821-3355
Fax: 281-821-0304

TORONTO:
90 Ironside Crescent,
Unit 12, Toronto,
Ontario, Canada M1X1M3
Tel: 416-291-3435
Fax: 416-291-0898

www.densona.com

A Member of Winn & Coales International

The information given on this sheet is intended as a general guide only and should not be used for specification purposes. We believe the information to be accurate and reliable but do not guarantee it. We assume no responsibility for the use of this information. Users must, by their own tests, determine the suitability of the products and information supplied by us for their own particular purposes. No patent liability can be assumed.